

Távirányító segédlet

Varga András Távirányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	AKAI ALX-2777							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	TV/AV							
TEXT	TXT/TV	Pip On/Off						
TV	TV/AV							
	Sleep							
	T_Subpage							
	T_Size							
	T_Mix							
	T_Cancel							
	T_Reveal							
	T_Hold							
	T_Index							
	Red							
	Green							
	Yellow							
	Blue							
	Sound	Nicam						
	CH+							
	Picture	Zoom						
	Vol-							
OK								
	Vol+							
MENU	Menu							
	CH-							
EXIT	Return/Rec							
VOL+	Vol+							
	Display							
CH+	CH+							
VOL-	Vol-							
MUTE	Mute							
CH-	CH-							
1	1	P_Position						
2	2	P_Swap						
3	3	P_Size						
4	4	P_Window						
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0							