

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	AKAI AX-1505WDV							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Open						
AV	Input	Input						
TEXT	TV/TXT	Title						
TV	Nicam/A2	Program						
	Sleep							
	Subtitle	Subtitle						
	T_Size	Zoom						
	Return	Repeat						
	T_Cancel	Angle						
	T_Reveal	Slow						
	T_Hold	Stop						
	T_Index	Play/Pause						
	Red							
	Green	Rev						
	Yellow	Play/Pause						
	Blue	Fwd						
	Sound	Language						
	▲	▲						
	Picture	Setup						
	◀	◀						
OK	OK	OK						
	▶	▶						
MENU	Sys Menu	Menu						
	▼	▼						
EXIT	Exit	A-B						
VOL+	Volume+	Vol+						
	Display							
CH+	Pr+	Next						
VOL-	Volume-	Vol-						
MUTE	Mute							
CH-	Pr-	Prev						
1	1	1						
2	2	2						
3	3	3						
4	4	4						
5	5	5						
6	6	6						
7	7	7						
8	8	8						
9	9	9						
	Pr/--	Pr/--						
0/10	0	0						
		Goto						