

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	DIGI DIGI-15							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Standby							
AV								
TEXT	TXT							
TV	TV/Rad	16:9						
	Subtitle							
	Back							
	Page-							
	Page+							
		Stop						
		Play/Pause						
	Red/Fav	Rec						
	Green/Sort	Rev						
	Yellow/Find	Play/Pause						
	Blue/Msg	Fwd						
	Audio							
OK	OK							
MENU	Menu							
EXIT	Exit							
VOL+	Vol+							
	Info							
CH+	CH+	Next						
VOL-	Vol-							
MUTE	Mute							
CH-	CH-	Prev						
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	App							
0/10	0							
	Fav							