

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	DIMARSON DM-LT32FHD							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV	Input	Media						
TEXT	Text							
TV	TV/Radio							
	Sleep	T.Shift						
	Subtitle	Subtitle						
	T-Size							
	Prev Pr.	Repeat						
	T-Subpage	A-B						
	T-Reveal							
	T-Hold	Stop						
	T-Index	Freeze						
	Red	Rec						
	Green	Rev						
	Yellow	Play/Pause						
	Blue	Fwd						
	S.Mode	Audio I/II						
	▲	▲						
	P.Mode	Aspect						
	◀	◀						
OK	OK	OK						
	▶	▶						
MENU	Menu	Home/Rec.						
	▼	▼						
EXIT	Exit	Exit						
VOL+	Volume+	Volume+						
	Display	Info						
CH+	CH+	Next						
VOL-	Volume-	Volume-						
MUTE	Mute	Mute						
CH-	CH-	Prev						
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--	Fav-						
0/10	0	Fav						
	Epg	Fav+						