

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ECHOSMART DSB792							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	SAT							
TEXT	i							
TV	TV/SAT	TV/Radio						
	Sleep							
	UHF							
	T/S							
	Pause							
	Red/TTX	Rec						
	Green/Sub.							
	Yellow/Zoo							
	Blue/?							
	Audio							
	CH+							
	Pal/Ntsc							
	Volume-							
OK	OK							
	Volume+							
MENU	Menu							
	CH-							
EXIT	Exit							
VOL+	Volume+							
	Recall							
CH+	CH+							
VOL-	Volume-							
MUTE	Mute							
CH-	CH-							
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	EPG							
0/10	0							
	Fav							