

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV								
TEXT	TTX							
TV	TV/Radio							
	Timeshift							
	Subtitle							
	Recall							
	Repeat							
	Rev	Prev						
	Fwd	Next						
		Stop						
	List	Pause						
	Red/Zoom	Rec						
	Green/Asp							
	Yellow/V-F	Play						
	Blue/Timer							
	Lang							
								
								
								
OK	OK							
								
MENU	Menu							
								
EXIT	Exit							
VOL+	Volume+							
	Info							
CH+	CH+	PgUp						
VOL-	Volume-							
MUTE	Mute							
CH-	CH-	PgDwn						
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	EPG							
0/10	0							
	Fav							