

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV								
TEXT								
TV								
	Delay							
	Subwoofer							
	-							
	Level							
	+							
	Sound							
	Top Menu							
OK	Enter							
MENU	Menu							
EXIT	Return							
VOL+	Volume+							
	Display							
CH+								
VOL-	Volume-							
MUTE	Muting							
CH-								
1	TV	1						
2	VCR	2						
3	DVD	3						
4	MD	4						
5	TUNER/Ba	5						
6	TAPE	6						
7	CD	7						
8		8						
9		9						
	SFC	>10/-/--						
0/10		0						
	Test	Dir.Tun.						