

## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV	Inp.Mode							
TEXT	Test							
TV	C.Focus							
								
								
								
								
								
								
								
	TV							
	VCR							
	DVD							
	Tuner/Band							
	Effect							
	H.Bass							
	Tone/Bal.							
	-/L							
OK								
	+/R							
MENU								
	Level							
EXIT	Subwoofer							
VOL+	Volume+							
								
CH+	CH+							
VOL-	Volume-							
MUTE	Muting							
CH-	CH-							
1	1	PLII						
2	2	Music						
3	3	AV/Movie						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0	Off						
	Dir.Tuning							