

## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	Inp.Select							
TEXT								
TV	Prog/Check	Dir.TV Rec						
	Timer	Time Slip						
								
	Manual							
	Ext.Link							
	Skip-	Rec.Mode						
	Skip+							
	Stop							
	Pause	Showview						
	Rec	Red/Displa						
	Slow/Searc	Green/Stat						
	Play	Yellow/Cre						
	Slow/Searc	Blue/Erase						
	Audio							
								
	Functions							
								
OK	Enter	Enter						
								
MENU	Top Menu	Sub Menu						
								
EXIT	Return							
VOL+								
	Display	i						
CH+	CH+							
VOL-								
MUTE	Dubbing							
CH-	CH-							
1	1	HDD						
2	2	DVD						
3	3	SD						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	Guide							
0/10	0							
	Cancel							