

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	AV	Source						
TEXT								
TV	TV	Auto						
	Sleep							
	Return							
	Prev							
	Next							
	Stop							
	Play/Pause							
	Rev							
	Play/Pause							
	Fwd							
	S.Mode							
	P.Mode							
OK	OK							
MENU	Menu							
EXIT	Exit							
VOL+	Volume+							
	Display							
CH+	CH+							
VOL-	Volume-							
MUTE	Mute							
CH-	CH-							
1	1	Pip/Pop						
2	2	HDMI						
3	3	VGA						
4	4	S-Video						
5	5	YPBPR						
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0							
	Media							