



















Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1) 338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ALCOR HD-2650 Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Standby							
AV	USB							
TEXT	TTX							
TV	TV/Radio							
								
	Subtitle							
								
	Recall							
	Prev							
	Next							
	Stop							
	Pause							
	Record	Red						
	Rew	Green						
	Play	Yellow						
	Fwd	Blue						
	Audio							
								
	Media							
								
OK	OK							
								
MENU	Menu							
								
EXIT	Exit							
VOL+	Vol+							
	Info							
CH+	CH+							
VOL-	Vol-							
MUTE	Mute							
CH-	CH-							
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	EPG							
0/10	0							
	Fav							