

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV	Input							
TEXT	TV/Text	Scale						
TV	TV							
	Sleep							
	T_Mix							
	T_Size							
	Recall							
	T_Cancel	T_Subcode						
	T_Reveal							
	T_Hold							
	T_Index	Freeze						
	R							
	G							
	Y							
	B							
	Snd	Nicam						
	Pic							
OK								
MENU	Menu							
EXIT								
VOL+	Vol+							
	Call							
CH+	Prog+							
VOL-	Vol-							
MUTE	Mute	Lang						
CH-	Prog-							
1	1	TV						
2	2	YPbPr						
3	3	PC						
4	4	HDMI						
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0							
	Recall							