

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ELTAX MOVIEBOXX							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Open/Close						
AV								
TEXT	Title	Prog						
TV	Pre/Tun							
	Subtitle							
	Zoom	Angle						
	Repeat							
	Slow							
	Stop							
	Pause							
	Rev/Memo							
	Play							
	Fwd/Auto							
	Audio							
	Setup							
OK	Enter							
MENU	Menu							
EXIT								
VOL+	Volume+							
	Disp							
CH+	Next							
VOL-	Volume-							
MUTE	Mute							
CH-	Prev							
1	1	DVD						
2	2	TUNER						
3	3	TV						
4	4	AUX						
5	5							
6	6							
7	7							
8	8							
9	9							
	+10							
0/10	0							
	Mono/CH							