

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Open/Close						
AV	Input Sel.							
TEXT								
TV	System							
	Timer Prog.	T.Set						
	Zoom							
	Repeat							
	Clear	CM Skip						
	Slow							
	Stop							
	Pause							
	Rec/OTR	Rec.Speed						
	Rev							
	Play							
	Fwd							
	Audio							
	Setup							
OK	Enter							
MENU	Menu/List	Top Menu						
EXIT	Return							
VOL+								
	Display							
CH+	Prog+	Next						
VOL-								
MUTE	Dubbing							
CH-	Prog-	Prev						
1	1	DVD						
2	2	VCR						
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
0/10	0							
	Search							