

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	FUNAI NB665							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Standby	Open/Close						
AV								
TEXT								
TV	Mode	Speed/Syst						
		T-Set						
	Subtitle							
	Zoom	Angle						
	Repeat	A-B						
	Clear/C.Re							
	Stop							
	Pause							
	Rec/Otr							
	Rev							
	Play							
	Fwd							
	Audio							
	Setup							
OK	Enter	Enter						
MENU	Menu	Top Menu						
EXIT	Return	Return						
VOL+	Channel+							
	Display							
CH+	Skip+							
VOL-	Channel-							
MUTE								
CH-	Skip-							
1	1	VCR						
2	2	DVD						
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	+10							
0/10	0							
	Search							