














Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

| Layout Keys | TV | | VCR/DVD | | SAT | | AUX | |
|---|-------------------|------------|---------|-------|--------|-------|--------|-------|
| | ORION ORION-04 | | | | | | | |
| | Direct | Shift | Direct | Shift | Direct | Shift | Direct | Shift |
|  | Standby | | | | | | | |
| AV | Source | | | | | | | |
| TEXT | TTX | List | | | | | | |
| TV | TV/Radio | Auto | | | | | | |
|  | Sleep | | | | | | | |
|  | Subtitle | | | | | | | |
|  | Size | | | | | | | |
|  | PR.Prev | | | | | | | |
|  | Cancel | Subpage | | | | | | |
|  | Reveal | | | | | | | |
|  | Hold | Stop | | | | | | |
|  | Index | Play/Pause | | | | | | |
|  | Red | Rec | | | | | | |
|  | Green | Rev | | | | | | |
|  | Yellow | Play/Pause | | | | | | |
|  | Blue | Fwd | | | | | | |
|  | S.Mode | Audio i/II | | | | | | |
|  | ▲ | Up | | | | | | |
|  | P.Mode | Aspect | | | | | | |
|  | ◀ | Left | | | | | | |
| OK | OK | OK | | | | | | |
|  | ▶ | Right | | | | | | |
| MENU | Menu | | | | | | | |
|  | ▼ | Down | | | | | | |
| EXIT | Exit | | | | | | | |
| VOL+ | Volume+ | | | | | | | |
|  | Info | | | | | | | |
| CH+ | CH+ | Next | | | | | | |
| VOL- | Volume- | | | | | | | |
| MUTE | Mute | | | | | | | |
| CH- | CH- | Prev | | | | | | |
| 1 | 1 | R.List | | | | | | |
| 2 | 2 | T.List | | | | | | |
| 3 | 3 | | | | | | | |
| 4 | 4 | | | | | | | |
| 5 | 5 | | | | | | | |
| 6 | 6 | | | | | | | |
| 7 | 7 | | | | | | | |
| 8 | 8 | | | | | | | |
| 9 | 9 | | | | | | | |
|  | EPG | | | | | | | |
| 0/10 | 0 | | | | | | | |
|  | Fav | | | | | | | |