














## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION ORION-05							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Standby							
AV	Source							
TEXT	TTX	List						
TV	TV/Radio	Auto						
	Sleep							
	Subtitle							
	Size							
	PR.Prev							
	Cancel	Subpage						
	Reveal							
	Hold	Stop						
	Index	Play/Pause						
	Red	Rec						
	Green	Rev						
	Yellow	Play/Pause						
	Blue	Fwd						
	S.Mode	Audio i/II						
	▲	Up						
	P.Mode	Aspect						
	◀	Left						
OK	OK	OK						
	▶	Right						
MENU	Menu							
	▼	Down						
EXIT	Exit							
VOL+	Volume+							
	Info							
CH+	CH+	Next						
VOL-	Volume-							
MUTE	Mute							
CH-	CH-	Prev						
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	EPG							
0/10	0							
	Fav							