

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	ORION ORION-11						ORION ORION-11 USB	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power					Power	
AV	Source							
TEXT	Text						Rec.List	
TV	TV/Radio	DTV/ATV						
	Sleep	Sub.Pg.						
	Subtitle						Subtitle	
	T_Size							
	Prev Pr.							
	Cancel							
	T_Reveal							
	T_Hold						Stop	
	T_Index						Play/Pause	
	Red						Rec	
	Green						Rev	
	Yellow						Play/Pause	
	Blue						Fwd	
	S.Mode							
	P.Mode	Aspect						
OK	Enter						Enter	
MENU	Menu						Menu	
EXIT	Exit						Exit	
VOL+	Vol+						Vol+	
	Display							
CH+	CH+						Next	
VOL-	Vol-						Vol-	
MUTE	Mute						Mute	
CH-	CH-						Prev	
1	1	Freeze						
2	2	MTS						
3	3	Time Shift						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	Guide							
0/10	0							
	Fav/List							