

## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV	VCR/VDP							
TEXT	CD							
TV	Tuner/Band							
	Sleep							
	Program							
	Test							
								
	Cancel							
	Stop	Stop						
	Pause	R.Play						
								
		Rev						
	Play	Play						
		Fwd						
	ProLogic							
	Surround+							
								
	Center-							
OK								
	Center+							
MENU								
	Surround-							
EXIT								
VOL+	Volume+	Volume+						
	EQ Space							
CH+								
VOL-	Volume-	Volume-						
MUTE	Muting	Muting						
CH-								
1	1	Deck 1/2						
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	>10							
0/10	0							
	Disc							