

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Learned RAK-SC957WK							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Auto OFF						
AV								
TEXT	Program							
TV	Cancel							
	Sleep							
	Repeat							
	Random							
	Stop							
		TAPE						
	Rev/Prev	CD						
	Play/Pause	TUNER						
	Fwd/Next	AUX						
	EQ	3D AI						
	Play/Pause							
	Rev/Prev							
OK								
	Fwd/Next							
MENU								
	R.Play/CH-							
EXIT								
VOL+	Volume+							
CH+	CH+/Play/							
VOL-	Volume-							
MUTE	Muting	S.Woofers						
CH-	CH-/R.Play							
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	>10							
0/10	0							
	Disc							