

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	- RC-D3-02 TV		- RC-D3-02 DVD					
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power		Power	Eject				
AV	Source		DVD/USB					
TEXT	Text		Title					
TV	TV/Radio		Pbc					
	Sleep							
	Scaler		Subtitle					
	T_Size		A-B					
	Recall		Repeat					
	Epg		Zoom-					
	T_Reveal		Zoom+					
	T_Hold		Stop					
	T_Index		Pause/Step					
	Red/Goto							
	Green/A-B		Rev					
	Yellow/Rep		Play					
	Blue/Angle		Fwd					
	S.Mode		Audio					
	▲		▲					
	P.Mode							
	◀		◀					
OK	OK		OK					
	▶		▶					
MENU	Setup		Menu					
	▼		▼					
EXIT	Exit		Exit					
VOL+	Vol+		Vol+					
	Call		Display					
CH+	Prog+		Next					
VOL-	Vol-		Vol-					
MUTE	Mute		Mute					
CH-	Prog-		Prev					
1	1		1					
2	2		2					
3	3		3					
4	4		4					
5	5		5					
6	6		6					
7	7		7					
8	8		8					
9	9		9					
	-/--		-/--					
0/10	0		0					
	Fav		Goto					