

## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	- RC4813							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	Source							
TEXT	Text							
TV	CH.List							
	Sleep							
	Format							
	Prev.Pr.							
		Stop						
		Pause						
	Red	Record						
	Green	Rev						
	Yellow	Play						
	Blue	Fwd						
	Audio/Lang	Audio/Lang						
	▲	▲						
	Home							
	◀	◀						
OK	OK	OK						
	▶	▶						
MENU	Menu	Q.Menu						
	▼	▼						
EXIT	Back	Exit						
VOL+	Volume+	Volume+						
	Help	Help						
CH+	Prog+	Prog+						
VOL-	Volume-	Volume-						
MUTE	Mute	Mute						
CH-	Prog-	Prog-						
1	1	My Button1						
2	2	Web						
3	3	Media						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	Epg							
0/10	0							
	Prev.Pr.							