

## Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 [www.taviranyitok.hu](http://www.taviranyitok.hu)

Layout Keys	TV		VCR/DVD		SAT		AUX	
	JVC RM-C1816S							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	AV							
TEXT	Text/Top							
TV	TV/DTV							
	Sleep							
	Subtitle							
	Zoom							
	F.T/L							
	Reveal							
	Hold							
	Index							
	Red							
	Green							
	Yellow							
	Blue							
	I/II	St.Wide						
OK	OK							
MENU	Menu							
EXIT	Back							
VOL+	Vol+							
	Info							
CH+	P+							
VOL-	Vol-							
MUTE	Mute							
CH-	P-							
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	Guide							
0/10	0							
	Fav							