

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	SONY RM-ED029							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power							
AV	Input							
TEXT	Text							
TV	TV/Radio	Dig./Ana.						
								
	Subtitle							
								
	Prev.Pr.							
								
	T_Reveal							
	T_Hold	Stop						
		Pause						
	Red	Record						
	Green	Rew						
	Yellow	Play						
	Blue	Fwd						
	Audio							
								
	Options	Screen						
								
OK	OK	OK						
								
MENU	Home	Top Menu						
								
EXIT	Return	Exit						
VOL+	Volume+	Volume+						
	Info							
CH+	Program+	Next						
VOL-	Volume-	Volume-						
MUTE	Mute	Mute						
CH-	Program-	Prev						
1	1	Sync Menu						
2	2	Pop Up						
3	3	3D						
4	4	Theatre						
5	5	I-Manual						
6	6	Scene						
7	7	Inter.Vid.						
8	8	Inter.Wid.						
9	9	Track ID						
	Guide							
0/10	0							
	Fav							