

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	BLUETECH TQL2301BT.001							
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Power	Power						
AV	Source	Media						
TEXT	Text	Text						
TV	TV/Radio	TV/Radio						
	Sleep	Time Shift						
	Subtitle	Subpage						
	T_Size							
	Pr.Prev	Mix						
	T_Cancel	Prev						
	T_Reveal	Next						
	T_Hold	Stop						
	T_Index	Play/Pause						
	Red	Rec						
	Green	Rev						
	Yellow	Play/Pause						
	Blue	Fwd						
	S.Mode	Audio I/II						
	▲	▲						
	P.Mode							
	◀	◀						
OK	OK	OK						
	▶	▶						
MENU	Menu	Menu						
	▼	▼						
EXIT	Exit	Exit						
VOL+	Volume+	Volume+						
	Display	Display						
CH+	CH+	CH+						
VOL-	Volume-	Volume-						
MUTE	Mute	Mute						
CH-	CH-	CH-						
1	1	Fav						
2	2	Fav-						
3	3	Fav+						
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0							
	EPG							