

Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	BLAUPUNKT UNF-RMC0001 TV		BLAUPUNKT UNF-RMC0001 DVD					
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	Standby		Standby					
AV	Source							
TEXT	Text							
TV	DTV		DVD					
	Sleep							
	Subtitle		Subtitle					
	T_Size		Zoom					
	Prev Pr.		Repeat	A-B				
			Angle					
	T_Hold		Stop/Eject					
	Rec.List		Play/Pause					
	Red							
	Green		Rev					
	Yellow		Play/Pause					
	Blue		Rev					
	S.Mode	Audio	Audio					
	▲		▲					
	P.Mode	Aspect	Setup					
	◀		◀					
OK	OK		OK					
	▶		▶					
MENU	Menu		Menu					
	▼		▼					
EXIT	Exit		Exit					
VOL+	Vol+		Vol+					
	Info		Info					
CH+	Prog+		Next					
VOL-	Vol-		Vol-					
MUTE	Mute		Mute					
CH-	Prog-		Prev					
1	1	DTV	1					
2	2	Radio	2					
3	3	USB	3					
4	4	DVD	4					
5	5		5					
6	6		6					
7	7		7					
8	8		8					
9	9		9					
	Guide							
0/10	0		0					
	Fav		Goto					