























Távírányító segédlet

Varga András Távírányító Specialista

Tel.: (06-1)-338-3160 Mobil: +36-30-756-2289 www.taviranyitok.hu

Layout Keys	TV		VCR/DVD		SAT		AUX	
	Direct	Shift	Direct	Shift	Direct	Shift	Direct	Shift
	- X64187R							
	Power	Power						
AV	AV							
TEXT	TV/Text							
TV	16:9							
	SuB							
	P100							
	Doub							
	Mix							
	Update							
	Rev							
	Hold							
	Purple							
	Red							
	Green							
	Yellow							
	Blue							
	Smart							
	▲							
	Smart							
	◀							
OK	OK							
	▶							
MENU	Menu							
	▼							
EXIT	PP							
VOL+	Vol+							
								
CH+	PR+							
VOL-	Vol-							
MUTE	Mute							
CH-	PR-							
1	1							
2	2							
3	3							
4	4							
5	5							
6	6							
7	7							
8	8							
9	9							
	-/--							
0/10	0							
	Swap							